

UK AX25 PACKET SSID's

0		User
1		BPQ NODE, Linux_Node
2	144MHz	2 Metre Node (User PMS)
3		Use for stand-alone CHAT Node
4	70MHz	4 Metre Node
5		TCPIP Host (User)
6	50MHz	6 Metre Node,
7	432/433MHz	70cm Node, (User)
8		KAM KNODE, XROUTER CHAT
9		Point to Point Link Interface
10		Point to Point Link Interface
11		Point to Point Link Interface
12		Point to Point Link Interface
13		Point to Point Link Interface
14		Point to Point Link Interface
15		Point to Point Link Interface